

SAN ANTONIO CONVENTION CENTER SECTION L3A



DIRECTIONS:
MIX COLD WATER AND EIGHT DROPS OF DISH SOAP IN A SPRAY BOTTLE AND SHAKE SOLUTION WELL. IF NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

NOTE: ALL MUNTINS ARE 2 1/2" WIDE

LABOR:
MEN= 4
TIME= 4HR

MATERIAL:
TRU-CLING
CLEAR CLING

EQUIPMENT:
1- SCISSOR LIFT
2- 8' LADDER

TOOLS:
SQUEEGEE
DISH SOAP
SPRAY BOTTLE
WATER
PAPER TOWELS
WINDEX

**GRAPHIC / GLASS PANEL
DIMENSIONS:**
A,D-G(1)= 45 1/2"W x 115 1/8"H
B,C(1)= 45 1/2"W x 19 7/8"H
H1= 46 1/8"W x 115 1/8"H
A-G(2)= 45 1/2"W x 117 1/4"H
H2= 46 1/8"W x 117 1/4"H
B,C(3)= 35"W x 77 1/8"H

L3-WC304

FREEMAN PLANTOUR