

DIRECTIONS:

MIX COLD WATER AND EIGHT DROPS OF DISH SOAP IN A SPRAY BOTTLE AND SHAKE SOLUTION WELL. IF NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

SAN ANTONIO CONVENTION CENTER SECTION L3A

NOTE: WINDOWS
A, B & C
ARE PARTIALY
BLOCKED BY WALL

TOOLS:
SQUEEGEE
DISH SOAP
SPRAY BOTTLE
WATER
PAPER TOWELS
WINDEX

NOTE: ALL
MUNTINS ARE
2¹/₂" WIDE

MATERIAL:
TRU-CLING
CLEAR CLING

EQUIPMENT:
1- SCISSOR LIFT
2- 8' LADDER

LABOR:
MEN= 4
TIME= 6HR

GRAPHIC / GLASS PANEL

DIMENSIONS:

A1= 25"W x 115¹/₈"H

B-K(1)= 45¹/₂"W x 115¹/₈"H

A2= 25"W x 117¹/₄"H

B-K(2)= 45¹/₂"W x 117¹/₄"H

L3-WC306

FREEMAN PLANTOUR

