

SAN ANTONIO CONVENTION CENTER SECTION L1C

TOOLS:

SQUEEGEE
DISH SOAP
SPRAY BOTTLE
WATER
PAPER TOWELS
WINDEX

EQUIPMENT:

SCISSOR LIFT

MATERIAL:

TRU-CLING/
CLEAR CLING

LABOR:

MEN= 2
TIME= 4HR

NOTE: THE

MUNTINS
ARE
2¹/₂" WIDE.

**DIRECTIONS:**

MIX COLD WATER AND EIGHT DROPS OF DISH SOAP IN A SPRAY BOTTLE AND SHAKE SOLUTION WELL. IF NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

**GLASS PANEL
DIMENSIONS:**

A,D(1)= 43³/₈"W x 53¹/₂"H
A,D(2)= 43³/₈"W x 83¹/₈"H
B,C(1)= 45³/₈"W x 53¹/₂"H
B,C(2)= 45³/₈"W x 83¹/₈"H

L1-WC116

FREEMAN PLANTOUR