

NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

MATERIAL: TRU-CLING CLEAR CLING

SPRAY BOTTLE WATER PAPER TOWELS **WINDEX**

L3-WC309

FREEMAN PLANTOUR