

SAN ANTONIO CONVENTION CENTER SECTION L1E

DIRECTIONS:
GRAPHICS WERE DESIGNED WITH A 1/4" OVERLAP. USE IT! MIX COLD WATER AND EIGHT DROPS OF DISH SOAP IN A SPRAY BOTTLE AND SHAKE SOLUTION WELL. IF NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

GLASS PANEL DIMENSIONS:
A,C(1)= 18^{1/8}"W x 93"H
B1= 84"W x 93"H
A,C(2,3)= 18^{1/8}"W x 44"H
B(2,3)= 84"W x 44"H

!!!IMPORTANT!:
THESE WINDOWS HAVE OLD TINT ON THE INSIDE AND SHOULD BE HANDLED WITH CARE WHEN INSTALLING AND TEARING OUT GRAPHIC.

TOOLS:
SQUEEGEE
DISH SOAP
SPRAY BOTTLE
WATER
PAPER TOWELS
WINDEX

EQUIPMENT:
SCISSOR LIFT

MATERIAL:
TRU-CLING
CLEAR CLING

NOTE: THE MUNTINS ARE 2^{1/2}" WIDE.

LABOR:
MEN= 2
TIME= 3HR



L1-WC135

FREEMAN PLANTOUR