

**DIRECTIONS:**

MIX COLD WATER AND EIGHT DROPS OF DISH SOAP IN A SPRAY BOTTLE AND SHAKE SOLUTION WELL. IF NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

**SAN ANTONIO  
CONVENTION CENTER  
SECTION L3A**



**EQUIPMENT:**

- 1- SCISSOR LIFT
- 2- 8' LADDER

**MATERIAL:**

- TRU-CLING
- CLEAR CLING

**NOTE:**

ALL MUNTINS ARE 2 1/2" WIDE

**LABOR:**

MEN= 4  
TIME= 7HR

**GRAPHIC / GLASS**

**PANEL DIMENSIONS:**

- A-I,L,M(1)= 45 1/2"W x 115 1/8"H
- J,K(1)= 45 1/2"W x 19 7/8"H
- A-M(2)= 45 1/2"W x 117 1/4"H
- J,K(3)= 35"W x 77 1/8"H

**TOOLS:**

- SQUEEGEE
- DISH SOAP
- SPRAY BOTTLE
- WATER
- PAPER TOWELS
- WINDEX

**L3-WC305**

**FREEMAN PLANTOUR**