

**DIRECTIONS:**

MIX COLD WATER AND EIGHT DROPS OF DISH SOAP IN A SPRAY BOTTLE AND SHAKE SOLUTION WELL. IF NEEDED, CLEAN SURFACE OF GLASS WITH WINDEX AND TOWEL FIRST. NEXT, SPRAY GLASS AND GRAPHIC WITH A LIBERAL AMOUNT OF SOLUTION BEFORE APPLYING GRAPHIC TO THE GLASS. LINE UP AND LEVEL OUT GRAPHIC ON GLASS. USE SQUEEGEE TO REMOVE SOLUTION FROM INBETWEEN GRAPHIC AND GLASS. WIPE THE GRAPHIC CLEAN OF SOLUTION RESIDUE BEFORE MOVING TO NEXT JOB.

SAN ANTONIO  
CONVENTION CENTER  
SECTION L1A

**OUTSIDE GLASS**

**DIMENSIONS:**

A1= 42<sup>3/4</sup>"W x 115<sup>1/8</sup>"H  
A2= 42<sup>3/4</sup>"W x 118<sup>1/2</sup>"H  
B-E(1)= 47<sup>1/4</sup>"W x 115<sup>1/8</sup>"H  
B-E(2)= 47<sup>1/4</sup>"W x 118<sup>1/2</sup>"H  
F1= 41<sup>1/4</sup>"W x 115<sup>1/8</sup>"H  
F2= 41<sup>1/4</sup>"W x 118<sup>1/2</sup>"H

**INSIDE GLASS**

**DIMENSIONS:**


A1= 41<sup>1/8</sup>"W x 115<sup>1/8</sup>"H  
A2= 41<sup>1/8</sup>"W x 118<sup>1/2</sup>"H  
B-E(1)= 45<sup>1/2</sup>"W x 115<sup>1/8</sup>"H  
B-E(2)= 45<sup>1/2</sup>"W x 118<sup>1/2</sup>"H  
F1= 39<sup>5/8</sup>"W x 115<sup>1/8</sup>"H  
F2= 39<sup>5/8</sup>"W x 118<sup>1/2</sup>"H

**OUTSIDE**

**GRAPHIC**

**DIMENSIONS:**

A= 23'1"W x 115<sup>1/8</sup>"H  
B= 23'1"W x 118<sup>1/2</sup>"H



**MATERIAL:**  
PRINT GRAPHIC IN MULTIPLE PIECES WITH AN OVERLAP IF USING **CONTROLTAC** MATERIAL. PRINT GRAPHIC AS ONE SOLID PIECE IF USING **TRU-CLING** OR **CLEAR CLING** MATERIAL.

**TOOLS:**  
SQUEEGEE  
DISH SOAP  
SPRAY BOTTLE  
WATER  
PAPER TOWELS  
WINDEX

**NOTE:** RUBBER SEAL INBETWEEN OUTSIDE WINDOWS ONLY IS **3/4" WIDE**

**LABOR:**  
MEN= 2  
TIME= 6HR

**NOTE:** FRAME INBETWEEN WINDOWS ON THE INSIDE IS **2 1/2" WIDE**, VERTICAL AND HORIZONTAL.

L1-WC103

FREEMAN PLANTOUR